



AC-9316X

NO.	DESCRIPTION	NO.	DESCRIPTION
1	BOLT	33	MOTOR COVER
2	CYLINDER HEAD	34	BOLT
3	AIR FILTER	35	FAN
4	CYLINDER COVER GASKET	36	CIRCLIP
5	VALVE PLATE	37	CONNECTOR
6	VALVE PLATE GASKET	38	FAN COVER
7	VALVE CLACK	39	NUT
8	PIN	40	DENTATION WASHER
9	CYLINDER	41	CAPACITANCE
10	CYLINDER GASKET	42	NUT
11	PISTON RING	43	UNILATERAL VALVE
12	PISTON	44	RELEASE PIPE
13	PISTON PIN	45	BOLT
14	CIRCLIP	46	DISCHARGE PIPE
15	BREATH PIPE	47	NUT
16	BOLT	50	WHEEL
17	CRANK CASE COVER	51	DRAIN COCK
18	OIL LEVELER GASKET	52	BLOT
19	OIL LEVELER	53	FOOT
20	BOLT	54	TANK
21	O CIRCLIP	55	BOLT
22	RUBBER GASKET	56	PLASTIC HANDLE
23	CONNECTING ROD	57	CORD & PLUG
24	HEX BOLT(LEFT)	58	INTERNAL WIRE
25	CRANK	59	REGULATOR VALVE
26	CRANK CASE	60	SAFETY VALVE
27	SEALING RING	61	PRESSURE GAUGE
28	BEARING 6204	62	PRESSURE SWITCH
29	STATOR	63	QUICK COUPLERS
30	ROTOR	64	SCREW
31	BEARING 6202	100	OVER LOAD PROTECTOR

BM20100401